

Embrey Builders, LLC

1020 N. E. Loop 410, Suite 700
San Antonio, TX 78209
Ph : (210) 824-6044 Fax: (210) 824-7656

RFI

To: Trent Perkins
Parkin Perkins Olsen
9330 LBJ Freeway, Suite 1055
Dallas, TX 75243
Ph: (214)221-2220 Fax: (214)221-2252

RFI #: 182
Date: 8/13/2012
Job: EB-02 Keller Springs Lofts
Phone: 877-777-5115

CC:

Subject: 6" transition step on #19

Drawing: 9/S3.04, 10/S3.04
Cost Impact: None

Spec Section:
Schedule Impact: None

Date Required: 8/14/2012

Request:
Trent,
We still have a question on the transition 6" step on #19. You had previously said that the soffit of the 10" slab and the 18" area was the same and that is the way detail 9/S3.04 shows it. However, the step is only 6" so when that is added to the 10" slab coming into the thickened area you only get 16" not 18". If you look at 10/S3.04 that detail does not reflect our situation on this pour. Please advise ASAP
Requested by: Bryan Pickler
Embrey Partners, Ltd.

Response:
You are correct. The slab thickness in this area should be 10" + 6" = 16" not 18". The 18" dimension in 10/S3.04 should be 16" instead.
Answered by: Trent Perkins
Parkin Perkins Olsen
Answered date: August 14, 2012