

**Embrey Builders, LLC**  
 1020 N. E. Loop 410, Suite 700  
 San Antonio, TX 78209  
 Ph: (210) 824-8044 Fax: (210) 824-7856

**RFI**

To: Trent Perkins  
 Parkin Perkins Olsen  
 9330 LBJ Freeway, Suite 1055  
 Dallas, TX 75243  
 Ph: (214)221-2220 Fax: (214)221-2252

RFI #: 187  
 Date: 9/4/2012  
 Job: EB-02 Keller Springs Lofts  
 Phone: 877-777-5115

CC: Ryan Faulds (B.G.O. Architects, Inc.)

Subject: Parapet walls supports

Drawing: 1/SS.02, 2/4.3  
 Cost Impact: None  
 Spec Section:  
 Schedule Impact: None

Request: We have parapet walls that are 10' tall, an example of this is 1SS.02 and 2/4.3 is there a minimum height that we should install additional support that ties back into the roof system for wind load? If so please provide the height and a drawing showing us how to structurally tie them in.

Date Required: 9/6/2012

Requested by: Bryan Pickler  
 Embrey Partners, Ltd.

Response:

Please see attached sketches.

R. Trent Perkins, PE  
 Parkin-Perkins-Olsen Consulting Engineering, Inc.


September 5, 2012

Answered by

Company

Date


Page 1 of 1



PARKIN - PERKINS - OLSEN  
 CONSULTING ENGINEERING, INC.  
 9330 LBJ Freeway Suite 1055  
 Dallas, Texas 75243

Project: Keller Springs Lofts  
 Addison, Texas

Project No.: 39155 Date: 09/05/2012 Drawing No.: SK-10



PARKIN - PERKINS - OLSEN  
 CONSULTING ENGINEERING, INC.  
 9330 LBJ Freeway Suite 1055  
 Dallas, Texas 75243

Project: Keller Springs Lofts  
 Addison, Texas

Project No.: 39155 Date: 09/05/2012 Drawing No.: SK-9