



NOTES: SILT FENCE


1. Posts which support the silt fence shall be installed on a slight angle toward the anticipated runoff source. The post must be embedded a minimum of 18 inches.
2. The toe of the silt fence shall be trenched in with a spade or mechanical trencher, so that the downslope face of the trench is flat and perpendicular to the line of flow. Where fence cannot be trenched in (e.g. pavement), weight fabric flap with washed gravel on the uphill side.
3. The trench must be a minimum of 6 inches deep and 6 inches wide to allow for the silt fence fabric to be laid in the ground and backfilled with compacted material.
4. Silt fence shall be securely fastened to each support post or to woven wire, which is in turn attached to the support post. There shall be a 6 inch double overlap, securely fastened where ends of fabric meet.
5. Inspection shall be made daily or after each rainfall. Repair or replacement shall be made promptly as needed.
6. Silt fence shall be removed when the site is completely stabilized so as not to block or impede storm flow or drainage.
7. Accumulated silt shall be removed when it reached a depth of 3 inches. The silt shall be disposed of at an approved site and in such a manner as to prevent flow under fence not contribute to additional siltation.

4' MIN. STEEL OR WOOD POSTS SPACED AT 5' TO 8' SOFTWOOD POSTS SHALL BE 3" MIN. IN. DIA. OR NOMINAL 2"x4" HARDWOOD POSTS SHALL HAVE A MIN. CROSS SECTION OF 1.5"x1.5" (3.8 cm x 3.8 cm).




SILT FENCE

ATTACHED THE WOVEN FABRIC USING EVENLY SPACED STAPLES OR LOCKING PLASTIC TIES FOR WOODEN POSTS AT A MAX. SPACING OF 6". USE LOCKING PLASTIC TIES OR SEWN VERTICAL POCKETS FOR STEEL POSTS AT SAME SPACING.




SECTION B




PLAN


TEMPORARY STONE CONSTRUCTION ENTRANCE / EXIT




DROP INLET PROTECTION (TYP)




SLOPE DETAIL
NO SCALE



SLOPE CREST ANCHOR METHOD "A" (NO TRENCH)
NO SCALE




STEP 1




STEP 2

SLOPE TRENCHING METHOD "B"
NO SCALE




STEP 1




STEP 2

SLOPE TRENCHING METHOD "C"
NO SCALE

COMMON ROW OF STAPLES, USING CORRECT STAPLE PATTERN, SHOULD BE STAPLED INTO EACH BLANKET. ONE STAPLE HOLDS BOTH BLANKETS TO THE SOIL.




SIDE SEAM ABUT STAPLE DETAIL
NO SCALE




SIDE SEAM OVERLAP STAPLE DETAIL
NO SCALE

- NOTES:**
1. STAPLE PATTERNS ARE DEPENDENT ON SITE CONDITIONS. SEE CURLEX® STAPLE PATTERN GUIDE FOR DETAILS.
 2. E-STAPLE® MAY BE USED IN PLACE OF WIRE STAPLES.




END ROLL OVERLAP
NO SCALE




BOTTOM OF SLOPE TERMINATION
NO SCALE

EROSION CONTROL BLANKET
NOT TO SCALE



CURB INLET PROTECTION
NOT TO SCALE



NO.	REVISION	BY	DATE

Addison! TOWN OF ADDISON
DALLAS COUNTY, TEXAS

WATER, SANITARY SEWER & STORM DRAIN
BROOKHAVEN CLUB DR, PONTE AVE & VITRUVIAN PARK

EROSION & SEDIMENT CONTROL DETAILS

icon Consulting Engineers, Inc. 250 W. Southlake Blvd., Suite 117
Civil Engineers - Designers - Planners Southlake, Tx 76092 (817) 552-6210

PROJECT	DESIGN	DRAWN	DATE	FILE	SHEET
5029-01	JAM	SAM	OCT 14, 2008	PW #2008-009	21

WATER, SANITARY SEWER, & STORM DRAIN IMPROVEMENTS - BROOKHAVEN CLUB DRIVE, PONTE AVENUE & VITRUVIAN PARK